

# Radar/LED Speed Sign Compatibility



| RADAR                              | 2 ½-DIGIT and 3 ½-DIGIT x 8-INCH LED SPEED SIGNS  | CABLE<br>(See note 1)   |
|------------------------------------|---|---|
| <b>STALKER PRO</b><br>(See note 3) | If using the corded interface handle on the radar (with no connector on the right side):<br><b>Sign:</b> 1 2 3 4 5 6 7 8<br>↑ ↓ ↓ ↓ ↓ ↓ ↓ ↓   | 155-2271-00<br>Radars without an RS-232 port require a Handle with Data Connector, 200-0163-02. |
|                                    | If using the RS232 format assembly on the radar (with connector on the right side):<br><b>Sign:</b> 1 2 3 4 5 6 7 8<br>↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓<br><b>Radar:</b> Format A, 9600 baud   | 155-2287-25<br>(See note 2)   |
| <b>STALKER SPORT</b>               | If using the corded interface handle on the radar (with no connector on the right side):<br><b>Sign:</b> 1 2 3 4 5 6 7 8<br>↑ ↓ ↓ ↓ ↓ ↓ ↓ ↓   | 155-2271-00<br>Radars without an RS-232 port require a Handle with Data Connector, 200-0163-02. |
|                                    | If using the RS232 version of the radar (with connector on the right side):<br><b>Sign:</b> 1 2 3 4 5 6 7 8<br>↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓<br><b>Radar:</b> Format A, 1200 baud   | 155-2287-25<br>(See note 2)   |
| <b>STALKER SPORT 2</b>             | <b>Sign:</b> All switches set to OFF ↓.<br><b>Radar:</b> 1200 or 9600 Baud, Format A or AP, whole and tenths units  | 155-2287-25   |
| <b>STALKER SOLO 2</b>              | <b>Sign:</b> All switches set to OFF ↓ in A format. Switch 6 ↑ for bE format.<br><b>Radar:</b> 1200 or 9600 Baud, Format A or bE, whole and tenths units  | 155-2287-25   |
| <b>JUGS PRO-SPORTS</b>             | <b>Sign:</b> All switches set to OFF ↓.<br><b>Radar:</b> 1200 or 9600 Baud, Format A or bE, whole and tenths units  | 155-2287-25   |
| <b>STALKER PRO II</b>              | <b>Sign:</b> All switches set to OFF ↓ in A format.<br><b>bE Format:</b> 1 2 3 4 5 6 7 8<br>↓ ↓ ↓ ↓ * * *<br>For Plate Speed                    ↑ ↓ ↓<br>For Release Speed                 ↓ ↑ ↓<br>For Hit Speed                        ↑ ↑ ↓<br><b>Radar:</b> 1200 or 9600 Baud, Format A or bE, whole and tenths units | 155-2284-00   |

\* RS-232 models only

- Notes:
1. The standard cable length for all signs is 20 feet unless otherwise noted. Longer cable lengths are available.
  2. Requires a Battery Handle (200-0480-00) or Corded Handle (200-0163-00).
  3. Stalker Pro requires software Version 7.2 for RS-232 or Version 4.2 for TTL version or higher. To check your version, press and hold the "Self Test" button and then power on the unit.

(continued)

**STALKER**<sup>®</sup> Sports Radar  
*The World Leader in Sports Speed Measurement*



**888-STALKER**

**StalkerSportsRadar.com**

# Radars/LED Speed Sign Compatibility



(continued from page 1)

| RADAR                           | 2 ½-DIGIT and 3 ½-DIGIT x 8-INCH LED SPEED SIGNS  | CABLE<br>(See note 1) |
|---------------------------------|---|-----------------------|
| STALKER ATS II                  | <p><b>Sign:</b> All switches set to OFF ↓ in A format.</p> <p><b>bE Format:</b>           1 2 3 4 5 6 7 8<br/>                              ↓ ↓ ↓ ↓ ↓ * * *</p> <p>For Plate Speed                   ↑ ↓ ↓<br/>For Release Speed               ↓ ↑ ↓<br/>For Hit Speed                    ↑ ↑ ↓</p> <p><b>Radar:</b> 1200 or 9600 Baud, Format A or bE, whole and tenths units</p> <p style="text-align: right;">} In Baseball Mode</p> | 155-2284-00           |
| JUGS Si Arcade                  | <p><b>Sign:</b> All switches set to OFF ↓.</p> <p><b>Radar:</b> 1200 or 9600 Baud, defaults to 1200.</p>  | 155-2312-20           |
| STALKER<br>Speed Sensor*        | <p><b>Sign:</b> All switches set to OFF ↓ in A and AF format.</p> <p><b>Sensor:</b> 1200 or 9600 Baud, Format A or AF, whole and tenths units</p>   | 155-2315-30           |
| STALKER<br>Pro II Speed Sensor* | <p><b>Sign:</b> All switches set to OFF ↓ in A format.</p> <p><b>bE Format:</b>           1 2 3 4 5 6 7 8<br/>                              ↓ ↓ ↓ ↓ ↓ * * *</p> <p>For Plate Speed                   ↑ ↓ ↓<br/>For Release Speed               ↓ ↑ ↓<br/>For Hit Speed                    ↑ ↑ ↓</p> <p><b>Sensor:</b> 1200 or 9600 Baud, Format A or bE, whole and tenths units</p>   | 155-2315-30           |

\* RS-232 models only

Note: 1. The standard cable length for all signs is 20 feet unless otherwise noted. Longer cable lengths are available

**888-STALKER**

**STALKER**® Sports Radar  
The World Leader in Sports Speed Measurement

applied concepts, inc.  
2609 Technology Drive ■ Plano, Texas 75074  
972.398.3780 ■ Fax 972.398.3781

**StalkerSportsRadar.com**

